



**GOVERNMENT OF INDIA  
MINISTRY OF RAILWAYS**

**TROUBLE SHOOTING MANUAL  
OF  
PLASSER MAKE WORK SITE TAMPER  
(08-32)**

**REPORT NO. TM -117**

**February-2008**

**RESEARCH DESIGNS AND STANDARDS ORGANISATION**

**LUCKNOW-226011**

## P\_R\_E\_F\_A\_C\_E

A large number of On-Track Machines are presently working on Indian Railways covering different works related to track maintenance and renewals. To improve utilization of these machines, it is important to reduce their downtime and repair them in the shortest possible time. In this context, need was felt to develop Trouble Shooting Manuals for different On-track Machines. The Trouble Shooting Manuals for Continuous Tamping Machine (CSM09-32), Ballast Cleaning Machine (BCM), Ballast regulating machine (BRM Model 66-4), TTM (UNO) & TTM (DUO), Point and Crossing Tamping Machine (Unimat), Point and Crossing Changing Machine (T-28) and Provisional Trouble Shooting Manuals for Dynamic Track Stabilizer (DGS), Shoulder Ballast Cleaning Machine (FRM-80) and PQRS have already been prepared and issued. This trouble shooting manual of Plasser make work site tamper (08-32) is also an effort in the same direction.

It is hoped that this manual will be quite useful for field staff attending breakdown of machines. However, there is always scope for improvement for which suggestions may be sent to the undersigned.

Lucknow.  
February 2008

Vijay Sharma  
Executive Director/TM  
RDSO/Lucknow-226011.

## EXPLANATORY NOTES

While preparing the Trouble Shooting Manual of Plasser make work site tamper (08-32) the terms used and their meanings are explained below:

- CHECK - Ensure a specific condition does (or does not) exist.
  
- INSPECT - Look for damage and defects including breakage, distortion cracks, corrosion and wear, check for leaks, security and that all items are completed.
  
- REPLACE - Remove old parts and substitute with a new or overhauled or reconditioned part. Fit new or overhauled or reconditioned part in place of missing part.
  
- OVERHAUL - Dismantle, examine, recondition or renew parts as necessary against given specifications, reassemble, inspect and test.

## INDEX

<b>S. NO.</b>	<b>DESCRIPTION</b>	<b>PAGE NO.</b>
1.	Engine	1-5
2	Machine General	6-33
3.	Hydraulic Pump	34-38
4.	Hydraulic Relief Valve	39-40
5.	Hydraulic Unloader Valve	41
6.	Hydraulic Motor	42
7.	General Safety Notes	43
8.	Acknowledgement.	44

## I. ENGINE

S. No.	Faults	Probable Causes	Remedial Actions
1.	Engine does not start	1. Emergency stop switch is pressed. 2. No fuel in the tank.  3. Shut down mechanism is stuck  4. Air in fuel system. 5. Governor is stuck. 6. Misconnection of starting switch.  7. Valve clearance is not proper. 8. Weak batteries.  9. Injectors not functioning properly.	1. Emergency stop switch should be in release position. 2. Fill fuel in the tank and bleed air from fuel system as given in following steps:  i) Loosen the bleed plug on the fuel filter and operate the priming pump until the fuel emerges free of bubbles. Tighten the bleed plug.  ii) Then loosen banjo plug on injection pump and operate the priming pump until fuel emerges free of bubbles. Tighten the banjo plug. 3. Check the electrical supply at coil. if it is ok, then lubricate the piston of shut down coil and mechanism with lub oil and operate it manually. If still not working, then coil may be defective. Replace it. 4. Bleed air from fuel system as explained in item no. 2 above. 5. Replace the complete fuel injection pump 6. Check starting switch and if any misconnection is noticed, rectify it.  7. Adjust the valve clearance as given in engine manual. 8. Check electrolyte level in the batteries. Terminals should be clean and the charging system should be working. Over-aged batteries should be replaced.  9. Remove defective injectors and get them overhauled/calibrated or replace them with new one.

S. No.	Faults	Probable Causes	Remedial Actions
2.	Engine running too hot.	<p>10. Valves not seating properly.</p> <p>1. Coolant level too low.</p> <p>2. Defective thermostat</p> <p>3. Defective water pump.</p> <p>4. V-belt for water pump needs adjustment.</p> <p>5. Oil cooler not working properly.</p> <p>6. Valve clearance is not proper.</p> <p>7. Air filter is choked.</p> <p>8. RPM of coolant fan is too low.</p>	<p>10. i) Check the valves spring and replace the broken spring if any.  ii) Lap the valves.  iii) Lap the valve seat, if required.</p> <p>1. Check coolant level and top up to the mark in the filler neck.</p> <p>2. Check thermostat as given in the following steps:</p> <p>i) Drain cooling water and catch it for reuse.</p> <p>ii) Loosen hose clamps, pull back hoses and then remove thermostat.</p> <p>iii) Heat the water in container to approx. 85° C and place thermostat in it. Maintain temperature of water by agitating</p> <p>iv) By short-circuiting and radiator opening, check whether the thermostat opens fully. If not, then install new thermostat.</p> <p>3. Check/repair the water pump.</p> <p>4. Check the V-belt tension. To adjust, release the guide pulley and regulate tension in the belt. Then tighten the guide pulley.  If required, replace the V-belt.</p> <p>5. Repair / replace the Oil Cooler.</p> <p>6. Adjust the valve clearance as explained in engine manual.</p> <p>7. Clean the air filter.</p> <p>8. Adjust the RPM of the motor to 1600. Check hydraulic system and change pump and motor if necessary.</p>

S. No.	Faults	Probable Causes	Remedial Actions
		9. Water radiator choked. 10. Radiator cap missing or worn out 11. Water hose too old.	9. Get the radiator cleaned. 10. Fit new cap. 11. Replace the water hose.
3.	Engine misfiring	1. Dirty fuel filter. 2. No / less fuel in tank. 3. Air in fuel system. 4. Defective Injector. 5. Valve clearance is not proper. 6. Fuel injection timing not proper.	1. Check fuel filters and if necessary Change it filter. 2. Fill fuel in the tank and follow steps as given in s. no.1, item no.2. 3. Bleed air from the fuel system as explained in s. no.1, item no.2. 4. Remove the defective injector and get them overhauled/calibrated/ replace with new one. 5 Adjust valve clearances as given in engine manual 6. Adjust the timings.
4.	Excessive engine smoking.	1. Engine oil level too high. 2. Defective injector 3. Valve clearance is not proper. 4. Air in fuel system. 5. Clogged air cleaner. 6. Excessive carbon on cylinder head and piston.	1. Check oil level. For this, draw dipstick and clean with lint-free cloth. Return dipstick, wait a little until the oil has wetted the dipstick. Then remove the dipstick again and check oil level. 2. Follow the s.no.1, item no.9. 3. Follow the s. no.1, item no.7. 4. Follow the s.no.1, item no.2. 5. Clean the element or change if required. 6. De-carbonise the engine.

S. No.	Faults	Probable Causes	Remedial Actions
5.	Engine stops	7. Engine overloaded. 1. No fuel. 2. Air in the fuel system. 3. Valve clearances are not proper. 4. Governor is stuck.	7. Check and reduce the load. 1. Fill fuel in the tank and follow the steps as given in s. no. 1, item no.2. 2. Bleed air from fuel system as explained in s. no.1, item no.2. 3. Adjust the valve clearances as explained in s.no.1, item no.7 above. 4. Replace complete fuel injection pump.
		5. Overheating of engine 6. Shut down circuit fails.	5. Take remedial action as given in s.no.5 below. 6. Check the electrical circuit and repair as required.
6.	Engine knocking	1. Incorrect Injector setting. 2. Mechanical damage to piston/cylinder.	1. Remove the faulty injector and get it reset or replace it with new one. 2. Get the engine top overhauled.
		3. Valve clearance is not proper. 4. Fuel injection timing is not proper.	3. Adjust the valve clearance as given in engine manual. 4. Correct the timings.
7.	Output of the engine too low	1. Dirty fuel filter and fuel line. 2. Air in fuel system. 3. Defective Injectors. 4. Valve clearances are not proper. 5. Air filter choked.	1. Check the fuel filters and if necessary change it. 2. Bleed the air from system as explained in s. no.1, item no.2. 3. Remove the defective injectors and get them overhauled or replace with new one. 4. Adjust the valve clearances as given in engine manual. 5. Clean the air filter element or replace if required.

S. No.	Faults	Probable Causes	Remedial Actions
		6. Improper compression	6. Engine needs to be top overhauled.
		7. Governor is stuck.	7. Replace the complete fuel injection pump.
8.	Oil pressure low.	1. Dirty lube oil filter.	1. Relace the lube oil filter.
		2. Oil control valve not working.	2. Repair the control valve or replace it.
		3. Dirty oil cooler	3. Clean the oil cooler.
9.	Oil film present in crank case ventilation	1. Incorrect compression.	1. Engine needs to be top overhauled
		2. Lube oil brands.	2. Use lube oil of proper brand and grade as recommended by the OEM.
10.	Engine speed is irregular.	1. Air in fuel system	1. Bleed air from the system as explained in s. no.1, item no.2.
		2. Governor is stuck.	2. Replace complete fuel injection pump.
11.	Fuel consumption too high.	1. Use of incorrect lube oil brand.	1. Use proper grade and quality lube oil.
		2. Incorrect setting of Injector.	2. Overhaul/ Replace the defective injectors.
		3. Incorrect engine timing.	3. Get the engine timing reset.
		4. Clogged air filter.	4. Clean the air filter.
		5. Poor compression	5. Engine needs to be top overhauled.
12.	Lube oil consumption too high.	1. Incorrect lube oil brand.	1. Use proper grade and quality lube oil as recommended by OEM.
		2. Poor compression	2. Engine needs to be top overhauled.
		3. Oil filter dirty.	3. Replace the filter.

## II. MACHINE GENERAL

S. No.	Faults	Probable Causes	Remedial Actions
1.	Only L.H.S Tamping unit is not coming downwards in working	1) Mechanical problem  2) Electrical problem	i) Tamping unit locks may not be removed physically. Check and do the needful. ii) Fork of L.H.S Tamping depth transducer may not be in position with mechanical fork of tamping bank. Check and do the needful.  a) If lock and fork found O.K .Then by operating all the electrical switches Q10 should come on program control. If not so, then problem may be in electrical circuit. Check it as follows. i) Tamping unit selector switch (lowering) may be towards RHS. If so then input signal X1E will be coming on program control. Put the switch in middle position. ii) Input signal X5A for LHS tamping unit lock should come on program control. If it is coming then limit switch for LH Tamping unit lock may be mull functioning or defective. Check and do the needful. iii) Output signal Q68 for work system "ON" should come on program control. b) Q0B→X0B should come on program control If not coming on, then do as follows- i) LHS tamping unit may not be in top position. For top position input signal X13 should come on program control and green LED should glow in PCB 2U21, If not so then adjust the top position of LHS tamping unit by potentiometer P11 on 2U21, or there may be any defect in PCB circuit. ii) Fuse si 1 of 2U21 may also be burned. Check and do the needful. iii) Check 24V supply at terminal 30Z of 2U21. If it is coming then relay Re3 may not getting ground signal due to any circuit defect in PCB. Check and do the needful. iv) Relay Re3 of 2U21 may also be defective. Check by replacing with new one and do the needful.

S. No.	Faults	Probable Causes	Remedial Actions
		<p>3) Hydraulic problem</p>	<p>v) If terminal 30z of 2U21 is showing 24V, then check it at terminal P15 in P.B. No. B50. If it is not coming there then brown wire of cable 50.23 may be damaged in between. Check and do the needful.</p> <p>vi) If terminal P15 is not showing the supply, then check it at coupler of proportional valve. If it is not found there then wire between P15 in B50 and coupler of proportional valve is damaged. Check and do the needful.</p> <p>vii) If +24V is found at coupler. Then coupler may be defective. Check and do the needful.</p> <p>If by operating the coil Is17 of proportional valve for LHS tamping unit lowering manually, It is not coming down. Then there is hydraulic problem. Check it as follows-</p> <p>i) Unloader valve for working pressure should be set at 140 bar. It can be checked in hydraulic pressure gauge on hydraulic control panel at position "1" of pressure gauge selector</p> <p>ii) Proportional valve for LHS tamping unit up/down may also be defective. Check it by manual operation after removing the coupler.</p> <p>iii) No. 16 pressure pipe for LHS tamping unit cylinder downwards may also be chocked. It may be possible due to deposition of rubber at the time of new fitment of end fitting. Do the needful.</p>
2.	Only R.H.S Tamping unit is not coming downwards in working	<p>1) Mechanical problem</p> <p>2) Electrical problem</p>	<p>i) Tamping unit locks may not be removed physically. Check and do needful.</p> <p>ii) Fork of R.H.S Tamping depth transducer may not be in position with mechanical fork of tamping bank. Check and do the needful.</p> <p>a) If lock and fork found O.K .Then by operating all the electrical switches Q11 should come on program control. If not so, then problem may be in electrical circuit. Check it as follows.</p>

S. No.	Faults	Probable Causes	Remedial Actions
			<ul style="list-style-type: none"> <li>ii) Tamping unit selector switch (lowering) may be towards LHS. If so then input signal X1D will be coming on program control. Put the switch in middle position.</li> <li>iii) Input signal X5B for RHS tamping unit lock should come on program control. If it is coming then limit switch for RH Tamping unit lock may be null functioning or defective. Check and do the needful.</li> <li>iv) Output signal Q68 for work system "ON" should come on program control.</li> <li>b) Q0B→X0B should come on program control If not coming, then do as follows- <ul style="list-style-type: none"> <li>i) RHS tamping unit may not be in top position. For top position input signal X14 should come on program control and green LED should glow in PCB 2U22, If not so then adjust the top position of RHS tamping unit by potentiometer P11 on 2U22, or there may be any defect in PCB circuit.</li> <li>ii) Fuse si 1 of 2U22 may also be burned. Check and do the needful.</li> <li>iii) Check 24V supply at terminal 30Z of 2U22. If it is coming then relay Re3 may not getting ground signal due to any circuit defect in PCB. Check and do the needful.</li> <li>iv) Relay Re3 of 2U22 may also be defective. Check by replacing with new one and do the needful.</li> <li>v) If terminal 30z of 2U22 is showing 24V,then check it at terminal P16 in P.B. No. B50. If it is not coming there then brown wire of cable 50.25 may be damaged in between. Check and do the needful.</li> <li>vi) If terminal P16 is not showing the supply, then check it at coupler of proportional valve. If it is not found there then wire between P16 in B50 and coupler of proportional valve is damaged. Check and do the needful.</li> <li>vii) If +24V is found at coupler. Then coupler may be defective. Check and do the needful.</li> </ul> </li> </ul>

S. No.	Faults	Probable Causes	Remedial Actions
		3) Hydraulic problem	<p>If by operating the coil Is18 of proportional valve for RHS tamping unit lowering manually, It is not coming down. Then there is hydraulic problem. Check it as follows-</p> <ul style="list-style-type: none"> <li>i) Unloader valve for working pressure should be set at 140 bar. It can be checked in hydraulic pressure gauge on hydraulic control panel at position "1" of pressure gauge selector</li> <li>ii) Proportional valve for RHS tamping unit up/down may also be defective. Check it by manual operation after removing the coupler.</li> <li>iii) No. 16 pressure pipe for RHS tamping unit cylinder downwards may also be chocked. It may be possible due to deposition of rubber at the time of new fitment of end fitting. Do the needful.</li> </ul>
3.	Machine is not moving forward without tamping	1) Electrical Problem	<p>If all concerned electrical control switches are in 'ON' position, then Q08→X08 should come on program control and machine will move in forward direction. If not coming, then do as follows.</p> <ul style="list-style-type: none"> <li>i) Working drive direction switch on P.B. No.B2 may be in neutral position. Put it in forward direction. For this yellow LED for input signal X22 should glow on program control.</li> <li>ii) Yellow LED for input signal X11 should glow on program control. If not so, then peddle switch for machine drive may malfunctioning. Check and do the needful.</li> <li>iii) Fuse si33 for QL3 plate may be blown. Check and do the needful.</li> <li>iv) Relay QL30 may be defective. Check by replacing by new one and do the needful.</li> <li>v) If all above found OK, then 24V supply should come at terminal QL30 in P.B.No. B50. If it is not coming there, then wire of cable 2.28 between P.B.no. B2 and B50 may be damaged. Check and do the needful.</li> </ul>

S. No.	Faults	Probable Causes	Remedial Actions
		<p>2. Hydraulic Problem</p>	<p>vi) If 24V is coming in P.B.No.50 at terminal QL30, then check it at coupler 1s22 of 4-way valve HY-24RSJ-ET for driving bogie front. If it is not coming there, then either wire between B50 and 1s22 may be damaged or coupler may also be damaged itself. Check and do the needful.</p> <p>i) Unloader valve for working pressure should be set at 140 bars. It can be checked in hydraulic pressure gauge on hydraulic control panel at position '1' at pressure gauge selector.</p> <p>ii) 4-way valve HY24RSJ-ET for driving bogie front may be defective. Check and do the needful.</p> <p>iii) Double shock valve HY157.27 for driving bogie front may be defective. It will be replaced.</p> <p>iv) Driving motor of driving bogie front HY916.N.500 may also be defective. Replace it with new one.</p>
4.	Machine is not moving forward during tamping	1) Electrical Problem	<p>If all concerned electrical control switches are in 'ON' position, then Q08→X08 should come on program control and machine will move in forward direction. If not coming, then do as follows.</p> <p>i) Working drive direction switch on P.B. No.B2 may be in neutral position. Put it in forward direction. For this yellow LED for input signal X22 should glow on program control.</p> <p>ii) Tamping cycle selector switch should be towards single insertion or double insertion. For this X27 or X28 should come on program control.</p> <p>iii) Signal Q80→Q'80 should come on programme control. If not coming, then check all the condition of Q80→Q'80 through logic program and do the needful.</p> <p>iv) Signal Q0E→X0E should not come on programme control. If coming, then check all the condition through logic program and do the needful.</p>

S. No.	Faults	Probable Causes	Remedial Actions
			<ul style="list-style-type: none"> <li>v) Output signal Q68 should come on programme control. If not coming, then check all the conditions for Q68 from logic program and do the needful.</li> <li>vi) In case of double insertion signal Q00→X00 should not come on program control. If coming, then check all the condition Q00→X00 through logic program and do the needful.</li> <li>vii) Fuse si33 for QL3 plate may be blown. Check and do the needful.</li> <li>viii) Relay QL30 may be defective. Check by replacing by new one and do the needful.</li> <li>ix) If all above found OK, then 24V supply should come at terminal QL30 in P.B.No. B50. If it is not coming there, then wire of cable 2.28 between P.B.no. B2 and B50 may be damaged. Check and do the needful.</li> <li>x) If 24V is coming in P.B.No.50 at terminal QL30, then check it at coupler 1s22 of 4-way valve HY-24RSJ-ET for driving bogie front. If it is not coming there, then either wire between B50 and 1s22 may be damaged or coupler may also be damaged itself. Check and do the needful.</li> </ul>
	2. Hydraulic Problem		<ul style="list-style-type: none"> <li>i) Unloader valve for working pressure should be set at 140 bars. It can be checked in hydraulic pressure gauge on hydraulic control panel at position '1' at pressure gauge selector.</li> <li>ii) 4-way valve HY24RSJ-ET for driving bogie front may be defective. Check and do the needful.</li> <li>iii) Double shock valve HY157.27 for driving bogie front may be defective. It will be replaced.</li> <li>iv) Driving motor of driving bogie front HY916.N.500 may also be defective. Replace it with new one.</li> </ul>

S. No.	Faults	Probable Causes	Remedial Actions
5.	Machine is not moving reverse during work	<p>1. Electrical Problem</p> <p>2. Hydraulic Problem</p>	<p>If all concerned electrical control switches are in 'ON' position, then Q09→X09 should come on program control and machine will move in reverse direction. If not coming, then do as follows.</p> <ul style="list-style-type: none"> <li>i) Working drive direction switch on P.B. No.B2 may be in neutral position. Put it in reverse direction. For this yellow LED for input signal X23 should glow on program control.</li> <li>ii) Yellow LED for input signal X11 should glow on program control. If not so, then peddle switch for machine drive may malfunctioning. Check and do the needful.</li> <li>iii) Fuse si33 for QL3 plate may be blown. Check and do the needful.</li> <li>iv) Relay QL31 may be defective. Check by replacing by new one and do the needful.</li> <li>v) If all above found OK, then 24V supply should come at terminal QL31 in P.B.No. B50. If it is not coming there, then wire of cable 2.28 between P.B.no. B2 and B50 may be damaged. Check and do the needful.</li> <li>vi) If 24V is coming in P.B.No.50 at terminal QL31, then check it at coupler 1s23 of 4-way valve HY-24RSJ-ET for driving bogie front. If it is not coming there, then either wire between B50 and 1s23 may be damaged or coupler may also be damaged itself. Check and do the needful.</li> </ul> <ul style="list-style-type: none"> <li>i) Unloader valve for working pressure should be set at 140 bars. It can be checked in hydraulic pressure gauge on hydraulic control panel at position '1' at pressure gauge selector.</li> <li>ii) 4-way valve HY24RSJ-ET for driving bogie front may be defective. Check and do the needful.</li> <li>iii) Double shock valve HY157.27 for driving bogie front may be defective. It will be replaced.</li> <li>iv) Driving motor of driving bogie front HY916.N.500 may also be defective. Replace it with new one.</li> </ul>

<b>S. No.</b>	<b>Faults</b>	<b>Probable Causes</b>	<b>Remedial Actions</b>
6.	Automatic lining is out of order	1. Electrical Problem	<p>For proper functioning output signal Q1A should come on program control. If not coming, then check whether Q0A →X0A is coming on program control or not, If it is also not coming then check the electrical circuit as follows.</p> <ul style="list-style-type: none"> <li>i) Q05→X05 should come on programme control, if not coming then check all conditions for the same through logic program.</li> <li>ii) Yellow LED for input signal X3D for lining control main switch on P.B.No..B7 should glow on programme control by operating the switch to 'ON' position, if not coming then either switch may be malfunctioning or orange/black wire of cable no. 2.23 between P.B. No. B2 and B7 may be damaged. Check and do the needful.</li> <li>iii) Measuring system preloading switch may be in neutral position. It should be towards LHS/RHS. For this yellow LED for input signal X4E or X4F should glow on programme control by operating the switch on P.B.No. B7. If not coming then either switch may be malfunctioning or wire of cable 2.23 for connector X4E or X4F may be damaged between P.B.No. B2 and B7. Check and do the needful.</li> <li>iv) LHS and RHS clamp unit should be in down position. For this yellow LED for input signal X24 and X25 should glow on program control. If not, then either blue/white or yellow/white or both wires of cable 50.1 and 50.2 between P.B.No. B2 and B50 may be damaged or cable 50.1 and 50.2 between P.B.No. B50 and magnetic sensor for LHS/RHS lifting unit lower position may be damaged. Check and do the needful.</li> <li>v) Yellow LED for input signal 2F should glow on program control. If not so, then brown/green wire of cable no. 2.23 between P.B.No. B2 and B7 may be damaged. Check and do the needful.</li> </ul>

S. No.	Faults	Probable Causes	Remedial Actions
			<ul style="list-style-type: none"> <li>vi) magnetic sensor for LHS/RHS lifting units lower position may also be malfunctioning. Replace the sensor.</li> <li>vii) By operating all electrical controls of lining, supply should come on terminal R17 in P.B.No. B50. If it is not coming then either Green/Red wire of cable 7.20 between P.B. No. B7 and B50 may be damaged or there is any problem in PCB EK 2286L-00(02) [7U6 ]. Check and do the needful.</li> <li>viii) If supply is coming at terminal R17 then check it at coupler 1s15 of servo valve for lining. If it is not coming there then wire of cable 50.55 between P.B.No. B50 and servo coupler may be damaged. Check and do the needful.</li> </ul>
7.	L.H. automatic levelling is out of order	<ul style="list-style-type: none"> <li>2. Hydraulic problem</li> <li>1) Electrical Problem</li> </ul>	<ul style="list-style-type: none"> <li>i) If electrical circuit found OK then the servo valve for lining may be malfunctioning. It may be reset or will be replaced.</li> <li>ii) Unloader valve should be set at 140 bar and safety valve at 175 bar.</li> <li>Check weather signal Q06→X06 is coming on program control or not by operating all electrical controls. If it is coming then electrical circuit is OK and problem is somewhere else. If Q06→X06 is not coming then check the electrical circuit as follows.</li> <li>i) In put signal X2E should come on program control. For this yellow LED should glow. If not so then either switch for levelling control 'ON' on P.B. No. B7 may be malfunctioning or Red/Yellow wire of cable 2.23 between P.B.No. B2 and B7 may be damaged. Check and do the needful.</li> <li>ii) Signal Q05→X05 should come on Program control. If not coming then check all the conditions for the same from logic program and do the needful.</li> <li>iii) Input signal X1E should not come on program control. For that yellow LED for X1E should not glow on program control. If glowing then tamping unit operation switch may be towards RH or malfunctioning. Check and do the needful.</li> </ul>

S. No.	Faults	Probable Causes	Remedial Actions
--------	--------	-----------------	------------------

- iv) Input signal to program control X32 should not come on program control. For that yellow LED for X32 should not glow on program control. If not so, then power driver FT2 on PCB EK-2041LV.02A (7U2) may be malfunctioning. It should be replaced.
- v) Input indication X48 and X49 for front measuring trolley and measuring trolley unlocked should come on program control. If not then any one limit switch of front measuring trolley and measuring trolley may be malfunctioning. If so then 24V supply should come at terminal V3 and V10 in P.B.No. B7 but limit switch will not operate. In this case replace the defective limit switch.
- vi) Wire no. X48 and/or X49 of cable 2.23 between P.B. No.B2 and terminal V3 and/or V10 in P.B. No.B7 may be damaged. Check and do the needful.
- vii) Wire of cable no. 4.4 and 4.5 between P.B.No. B4 and limit switch for front trolley RHS/LHS may be damaged. Check and do the needful.
- viii) Wire V10 of cable 7.7 and 7.8 between P.B.No. B7 and limit switch for measuring trolley RHS/LHS may be damaged. Check and do the needful.
- ix) Input signal X24 for sensor of LHS clamp unit down or X2F for Rail sensor 'ON' should come on program control. If X24 is not coming on program control, then blue/white wire X24 of cable 2.27 between P.B.No. B2 and B50 may be damaged. Check the continuity and do the needful.
- x) Wire of cable 50.1 between P.B.No. B50 and magnetic sensor for LHS lifting unit may be damaged. Check and do the needful..
- xi) Magnetic sensor for LHS lifting unit may also be malfunctioning. Replace the sensor.
- xii) Q02→X02 should not come on program control. If coming, then check all the conditions for the same from program logic.

S. No.	Faults	Probable Causes	Remedial Actions
		<p>2) Mechanical Problem</p> <p>3) Hydraulic Problem</p>	<p>xiii) Relay QL2E may also be defective . Check by replacing with new one.and do the needful.</p> <p>xiv) Fuse si 32 may also be blown. If no one output signal is coming on QL2 plate, fuse have to be replaced.</p> <p>xv) If fuse and relay found OK , then yellow /black wire QL2E between P.B.No. B2 and B50 may be damaged. Check the continuity and do the needful.</p> <p>xvi) QL2E wire between P.B.No. B50 and 4-way valve HY-10RSG-B for LH Rail clamp lifting may be damaged. Check and do the needful.</p> <p>i) Either both front measuring and measuring trolley or any one may not be unlocked and lowered properly. Check physically and do the needful.</p> <p>ii) LHS levelling chord wire may be broken. Check and do the needful.</p> <p>If electrical circuit found OK then check the hydraulic pressures.</p> <p>i) Unloader valve should be set at 140 bar.</p> <p>ii) Safety valve should be set at 175 bar.</p> <p>iii) Operate the 4-way valve HY10 RSG-B for LHS lifting unit. If lifting unit is not operating, then either the valve or concerned servo valve may be defective. Check and do the needful.</p> <p>iv) Pressure filter for servo valve of LHS lifting unit may also be choked. Replace the same.</p>
8.	R.H. automatic levelling is out of order	1) Electrical Problem	<p>Check weather signal Q07→X07 is coming on program control or not by operating all electrical controls. If it is coming then electrical circuit is OK and problem is somewhere else. If Q07→X07 is not coming then check the electrical circuit as follows.</p> <p>i) In put signal X2E should come on program control. For this yellow LED should glow. If not so then either switch for levelling control 'ON' on P.B. No. B7 may be malfunctioning or Red/Yellow wire of cable 2.23 between P.B.No. B2 and B7 may be damaged. Check and do the needful.</p>

S. No.	Faults	Probable Causes	Remedial Actions
--------	--------	-----------------	------------------

- ii) Signal Q05→X05 should come on Program control. If not coming then check all the conditions for the same from logic program and do the needful.
- iii) Input signal X1D should not come on program control. For that yellow LED for X1D should not glow on program control. If glowing then tamping unit operation switch may be towards LH or malfunctioning. Check and do the needful.
- iv) Input signal to program control X33 should not come on program control. For that yellow LED for X33 should not glow on program control. If not so, then power driver FT2 on PCB EK-2041LV.02A (7U4) may be malfunctioning. It should be replaced.
- v) Input indication X48 and X49 for front measuring trolley and measuring trolley unlocked should come on program control. If not then any one limit switch of front measuring trolley and measuring trolley may be malfunctioning. If so then 24V supply should come at terminal V3 and V10 in P.B.No. B7 but limit switch will not operate. In this case replace the defective limit switch.
- vi) Wire no. X48 and/or X49 of cable 2.23 between P.B. No.B2 and terminal V3 and/or V10 in P.B. No.B7 may be damaged. Check and do the needful.
- vii) Wire of cable no. 4.4 and 4.5 between P.B.No. B4 and limit switch for front trolley RHS/LHS may be damaged. Check and do the needful.
- viii) Wire V10 of cable 7.7 and 7.8 between P.B.No. B7 and limit switch for measuring trolley RHS/LHS may be damaged. Check and do the needful.
- ix) Input signal X25 for sensor of RHS clamp unit down or X2F for Rail sensor 'ON' should come on program control. If X24 is not coming on program control, then yellow/white wire X25 of cable 2.27 between P.B.No. B2 and B50 may be damaged. Check the continuity and do the needful.

S. No.	Faults	Probable Causes	Remedial Actions
			<ul style="list-style-type: none"> <li>x) Wire of cable 50.2 between P.B.No. B50 and magnetic sensor for RHS lifting unit may be damaged. Check and do the needful..</li> <li>xi) Magnetic sensor for RHS lifting unit may also be malfunctioning replace the sensor.</li> <li>xii) Q03→X03 should not come on program control. If coming, then check all the conditions for the same from program logic.</li> <li>xiii) Relay QL2F may also be defective. Check by replacing with new one.and do the needful.</li> <li>xiv) Fuse si 32 may also be blown. If no one output signal is coming on QL2 plate, fuse have to be replaced.</li> <li>xv) If fuse and relay found OK , then blue/black wire QL2F between P.B.No. B2 and B50 may be damaged. Check the continuity and do the needful.</li> <li>xvi) QL2F wire between P.B.No. B50 and 4-way valve HY-10RSG-B for RH Rail clamp lifting may be damaged. Check and do the needful.</li> </ul>
	2) Mechanical Problem		<ul style="list-style-type: none"> <li>i) Either both front measuring and measuring trolley or any one may not be unlocked and lowered properly. Check physically and do the needful.</li> <li>ii) RHS levelling chord wire may be broken. Check and do the needful.</li> </ul>
	3) Hydraulic Problem		<p>If electrical circuit found OK then check the hydraulic pressures.</p> <ul style="list-style-type: none"> <li>i) Unloader valve should be set at 140 bar.</li> <li>ii) Safety valve should be set at 175 bar.</li> <li>iii) Operate the 4-way valve HY10 RSG-B for RHS lifting unit. If lifting unit is not operating, then either the valve or concerned servo valve may be defective. Check and do the needful.</li> <li>iv) Pressure filter for servo valve of RHS lifting unit may also be choked. Replace the same.</li> </ul>



S. No.	Faults	Probable Causes	Remedial Actions
10.	RHS front clamp is not getting open	<p>1) Electrical problem</p> <p>2) Hydraulic problem</p>	<p>i) Switch for clamp unit always close should be in 'OFF' position.</p> <p>ii) Q62→X62 should not come on program control. If coming then check all the conditions from program logic and do the needful.</p> <p>iii) Switch for rear clamp close should be in 'ON' position.</p> <p>iv) Switch for right clamp should be in 'ON' position.</p> <p>v) Q63→X63 should not come on program control. If coming then check all the conditions from program logic and do the needful.</p> <p>vi) If all the above conditions are fulfilling but still clamps are not getting open then do as follows.</p> <p>a) Check 24V at coupler 1s453 of 4-way valve for RH front clamp open/close. If it is found there, then 4-way valve is stick up or defective. Check and do the needful</p> <p>b) If 24V is not found at coupler, then check it at terminal QL36 in PB no. B50. If it is found there then wire between coupler and B50 is damaged. Check and do the needful.</p> <p>c) If 24V is not found at B50 then either relay QL36 may be defective or wire between B50 and QL36 may be damaged. Check and do needful.</p> <p>i) Unloader valve should be set at 140 bar.</p> <p>ii) Safety valve should be set at 175 bar.</p> <p>iii) Spool of 4-way valve HY6RSJ-B for RHS front clamp open/close may also be stickup. Check and do the needful.</p>

S. No.	Faults	Probable Causes	Remedial Actions
11.	LHS rear rail clamp is not getting open	<p>1) Electrical problem</p> <p>2) Hydraulic problem</p>	<p>i) Switch for clamp unit always close should be in 'OFF' position.</p> <p>ii) Q62→X62 should not come on program control. If coming then check all the conditions from program logic and do the needful.</p> <p>iii) Switch for front clamp close should be in 'ON' position.</p> <p>iv) Q63→X63 should not come on program control. If coming then check all the conditions from program logic and do the needful. .</p> <p>v) Switch for right clamp should be in 'ON' position.</p> <p>vi) If all the above conditions are fulfilling but still clamps are not getting open then do as follows.</p> <p>a) Check 24V at coupler 1s487A of 4-way valve for LH rear clamp open/close. If it is found there, then 4-way valve is stick up or defective. Check and do the needful</p> <p>b) If 24V is not found at coupler, then check it at terminal QL33 in PB no. B50. If it is found there then wire between coupler and B50 is damaged. Check and do the needful.</p> <p>c) If 24V is not found at B50 then either relay QL33 may be defective or wire between B50 and QL33 may be damaged. Check and do the needful.</p> <p>i) Unloader valve should be set at 140 bar.</p> <p>ii) Safety valve should be set at 175 bar.</p> <p>iii) Spool of 4-way valve HY6RSJ-B for LHS rear clamp open/close may also be stickup. Check and do the needful.</p>

S. No.	Faults	Probable Causes	Remedial Actions
12.	RHS rear rail clamp is not getting open	<p>1) Electrical problem</p> <p>2) Hydraulic problem</p>	<p>i) Switch for clamp unit always close should be in 'OFF' position.</p> <p>ii) Q62→X62 should not come on program control. If coming then check all the conditions from program logic and do the needful. .</p> <p>iii) Switch for front clamp close should be in 'ON' position.</p> <p>iv) Q63→X63 should not come on program control. If coming then check all the conditions from program logic and do the needful.</p> <p>v) Switch for left clamp should be in 'ON' position. If all the above conditions are fulfilling but still clamps are not getting open then do as follows.</p> <p>a) Check 24V at coupler 1s454 of 4-way valve for RH rear clamp open/close. If it is found there, then 4-way valve is stick up or defective. Check and do the needful.</p> <p>b) If 24V is not found at coupler, then check it at terminal QL37 in PB no. B50. If it is found there then wire between coupler and B50 is damaged. Check and do the needful.</p> <p>c) If 24V is not found at B50 then either relay QL37 may be defective or wire between B50 and QL37 may be damaged. Check and do the needful.</p> <p>i) Unloader valve should be set at 140 bar.</p> <p>ii) Safety valve should be set at 175 bar.</p> <p>iii) Spool of 4-way valve HY6RSJ-B for RHS rear clamp open/close may also be stickup. Check and do the needful.</p>

S. No.	Faults	Probable Causes	Remedial Actions
13.	LHS front rail clamp is not getting close	<p>1) Electrical problem</p> <p>2) Hydraulic problem</p>	<p>i) Switch for rear clamp close should be in 'OFF' position.</p> <p>ii) Switch for right clamp should be in 'OFF' position</p> <p>iii) Q62→X62 should come on program control. If not coming then check all the conditions from program logic and do the needful.</p> <p>iv) Q68→X68 should come on program control. If not coming then check all the conditions from program logic and do the needful. If all the above conditions are fulfilling but still clamps are not getting open then do as follows.</p> <p>a) Check 24V at coupler 1s486B of 4-way valve for LH front clamp open/close. If it is found there, then 4-way valve is stick up or defective. Check and do needful</p> <p>b) If 24V is not found at coupler then check it at terminal QL29 in PB no. B50. If it is found there then wire between coupler and B50 is damaged. Check and do needful.</p> <p>c) If 24V is not found at B50 then either relay QL29 may be defective or wire between B50 and QL29 may be damaged. Check and do the needful.</p> <p>i) Unloader valve should be set at 140 bar.</p> <p>ii) Safety valve should be set at 175 bar.</p> <p>iii) Spool of 4-way valve HY6RSJ-B for LHS front clamp open/close may also be stickup. Check and do the needful.</p>

S. No.	Faults	Probable Causes	Remedial Actions
14.	LHS rear rail clamp is not getting close	<p>1) Electrical problem</p> <p>2) Hydraulic problem</p>	<p>i) Switch for front clamp close should be in 'OFF' position.</p> <p>ii) Switch for right clamp should be in 'OFF' position.</p> <p>iii) Q62→X62 should come on program control. If not coming then check all the conditions from program logic and do the needful.</p> <p>iv) Q68→X68 should come on program control. If not coming then check all the conditions from program logic and do the needful.</p> <p>v) If all the above conditions are fulfilling but still clamps are not getting open then do as follows.</p> <p>a) Check 24V at coupler 1s487B of 4-way valve for LH rear clamp open/close. If it is found there, then 4-way valve is stick up or defective. Check and do the needful</p> <p>b) If 24V is not found at coupler then check it at terminal QL2A in PB no. B50. If it is found there then wire between coupler and B50 is damaged. Check and do needful.</p> <p>c) If 24V is not found at B50 then either relay QL2A may be defective or wire between B50 and QL2A may be damaged. Check and do the needful.</p> <p>i) Unloader valve should be set at 140 bar.</p> <p>ii) Safety valve should be set at 175 bar.</p> <p>iii) Spool of 4-way valve HY6RSJ-B for LHS rear clamp open/close may also be stickup. Check and do the needful.</p>



<b>S. No.</b>	<b>Faults</b>	<b>Probable Causes</b>	<b>Remedial Actions</b>
16.	RHS rear rail clamp is not getting close	<p>1) Electrical problem</p> <p>2) Hydraulic problem</p>	<p>i) Switch for front clamp close should be in 'OFF' position.</p> <p>ii) Switch for right clamp should be in 'OFF' position.</p> <p>iii) Q62→X62 should come on program control. If not coming then check all the conditions from program logic and do the needful.</p> <p>iv) Q68→X68 should come on program control. If not coming then check all the conditions from program logic and do the needful.</p> <p>v) If all the above conditions are fulfilling but still clamps are not getting open then do as follows.</p> <p>a) Check 24V at coupler 1s29 of 4-way valve for RH rear clamp open/close. If it is found there, then 4-way valve is stick up or defective. Check and do the needful</p> <p>b) If 24V is not found at coupler ,then check it at terminal QL3B in PB no. B50. If it is found there then wire between coupler and B50 is damaged. Check and do the needful.</p> <p>c) If 24V is not found at B50 then either relay QL3B may be defective or wire between B50 and QL3B may be damaged. Check and do the needful.</p> <p>i) Unloader valve should be set at 140 bar.</p> <p>ii) Safety valve should be set at 175 bar.</p> <p>iii) Spool of 4-way valve HY6RSJ-B for RHS rear clamp open/close may also be stickup. Check and do the needful.</p>







S. No.	Faults	Probable Causes	Remedial Actions
		<p>2) Hydraulic Problem</p>	<p>iii) If 24V is not found at terminal QL25 in P.B.NO. B50. Then check the grey/green wire of cable 2.28 between B50 and B2.It may be damaged. Check the continuity and do the needful.</p> <p>iv) If all wires are OK. Then relay QL25 may also be defective. Check and do the needful.</p> <p>i) Unloader valve HY511.12 should be set at 140 bar.</p> <p>ii) Safety valve HY511.15 should be set at 175 bar.</p> <p>iii) 4-way valve (HY16RSD-ET) may also not functioning properly. Check and do the needful.</p>
21.	Tamping Units are not moving towards LHS/RHS	<p>1) Electrical problem</p> <p>2) Hydraulic problem</p>	<p>If by operating the concerned valve manually, T/units are not moving LHS/RHS. Then check 24V at coupler 1s49/1s50 of 4-way valve HY24RSJ-B by operating all the electrical controls. If it is not coming there, then check the electrical circuit as follows.</p> <p>i) Check connector QL20/QL21 in P.B. No. B50.If it is coming there, then brown wire of cable no. 50.26 between 1s49/1s50 and P.B. No. B50 may be damaged. Check the continuity and do the needful.</p> <p>ii) If 24V is not coming at connector QL20/QL21 in P.B.No. B50. Then check it at connector QL20/QL21 in P.B.No.B2.If it is coming there, then red-yellow/brown-green wire of cable no.2.28 between P.B No. B50 may be damaged. Check the continuity and do the needful.</p> <p>iii) Fuse si32 of QL2 plate may also be blown. Check and do the needful.</p> <p>iv) Relay QL 20/QL21 may also be blown. Check and do the needful.</p> <p>i) If by operating the concerned valve manually. Tamping units are not moving LHS/RHS. Then spool of 4-way valve may be stick up. Check and do the needful.</p> <p>ii) Safety valve should be set at 175 bar. Check and do the needful.</p> <p>iii) Unloader valve should be set at 140 bar. Check and do the needful.</p>



S. No.	Faults	Probable Causes	Remedial Actions
		<p>2) Hydraulic problem</p>	<p>ii) If 24V is not coming at connector QL2F in P.B. No. B50. Then check it at connector QL2F in P.B.No. B2. If it is found there, then blue/black wire of cable 2.28 may be damaged. Check and do the needful.</p> <p>iii) Fuse si32 of QL2 plate may be blown. Check and do the needful.</p> <p>iv) Relay QL2F may also be blown. Check and do needful.</p> <p>If by operating the concerned valve manually, RHS clamp unit is not going upward. Then check the hydraulic circuit as follows.</p> <p>i) Check servo valve filter indication (RHS) and the do needful.</p> <p>ii) Unloader valve HY511.11 should be set at 140 bar.</p> <p>iii) Safety valve should be set at 175 bar.</p> <p>iv) If all above found OK. Then servo valve EL-T76.00MO may be defective. Check and adjust the null point or replace it.</p>
24.	LHS clamp unit is not coming downward	1) Electrical problem	<p>If by operating all the electrical controls, LHS clamp unit is not coming downward. Then operate the coil 1s8 of concerned valve manually. If clamp unit is coming downward, then problem is in electrical circuit. Check it as follows.</p> <p>i) Check 24V at coupler 1s8 of concerned valve. If it is not found there, then check it at connector QL2B in P.B.No. B50. If it is coming there, then brown wire of cable no. 50.38 between coil 1s8 and connector QL2B in P.B. No. B50 may be damaged. Check the continuity and do the needful.</p> <p>ii) If 24V is not coming at connector QL2B in P.B. No. B50. Then check it at connector QL2B in P.B.No. B2. If it is found there, then violet/black wire of cable 2.28 may be damaged. Check and do the needful.</p> <p>iii) Fuse si32 of QL2 plate may be blown. Check and do the needful.</p> <p>iv) Relay QL2B may also be blown. Check and the do needful.</p>

S. No.	Faults	Probable Causes	Remedial Actions
		2) Hydraulic problem	<p>If by operating the concerned valve manually, LHS clamp unit is not coming downward. Then check the hydraulic circuit as follows.</p> <ul style="list-style-type: none"> <li>i) Spool of 4-way valve HY10RSG-B for LHS clamp lifting/ lowering may be stick up. Check and do the needful.</li> <li>ii) Unloader valve HY511.11 should be set at 140 bar.</li> <li>iii) Safety valve HY511.15 should be set at 175 bar.</li> </ul>
25.	RHS clamp unit is not coming downward	<p>1) Electrical problem</p> <p>2) Hydraulic problem</p>	<p>If by operating all the electrical controls, RHS clamp unit is not coming downward. Then operate the coil 1s9 of concerned valve manually. If clamp unit is coming downward, then problem is in electrical circuit. Check it as follows.</p> <ul style="list-style-type: none"> <li>i) Check 24V at coupler 1s9 of concerned valve. If it is not found there, then check it at connector QL2C in P.B.No. B50. If it is coming there, then brown wire of cable no. 50.39 between coil 1s9 and connector QL2C in P.B. No. B50 may be damaged. Check the continuity and do the needful.</li> <li>ii) If 24V is not coming at connector QL2C in P.B. No. B50. Then check it at connector QL2C in P.B.No. B2. If it is found there, then green/black wire of cable 2.28 may be damaged. Check and do the needful.</li> <li>iii) Fuse si32 of QL2 plate may be blown. Check and do the needful.</li> <li>iv) Relay QL2C may also be blown. Check and do the needful.</li> </ul> <p>If by operating the concerned valve manually, RHS clamp unit is not coming downward. Then check the hydraulic circuit as follows.</p> <ul style="list-style-type: none"> <li>i) Spool of 4-way valve HY10RSG-B for LHS clamp lifting/ lowering may be stick up. Check and do the needful..</li> <li>ii) Unloader valve HY511.11 should be set at 140 bar.</li> <li>iii) Safety valve HY511.15 should be set at 175 bar.</li> </ul>

### III. HYDRAULIC PUMP

S. No.	Faults	Probable Causes	Remedial Actions
1.	Pump not delivering oil.	<ol style="list-style-type: none"> <li>1. Pump driven in wrong direction (at the time of new pump fitment, this problem may occur).</li> <li>2. Oil level too low in the reservoir (if oil level is very low, aeration may take place and pump will not deliver oil).</li> <li>3. Intake filter/pipe choked.</li> <li>4. Air leaks at pump intake joints.</li> <li>5. Broken pump shaft or rotor.</li> <li>6. Pump speed too slow. (The delivery rate of discharge is prescribed at a certain rpm of engine. If engine speed become less than ideal speed, it may affect the proper suction of oil).</li> <li>7. Dirty suction filter</li> <li>8. Faulty suction valve.</li> <li>9. Air in system.</li> </ol>	<ol style="list-style-type: none"> <li>1. Check the pump rotation by hand priming. Pour the hydraulic oil into inlet port and rotate the shaft. See whether the oil is delivering through outlet port or not. If not, change the rotation according to the engine shaft rotation.</li> <li>2. Check oil level in reservoir. It should be above minimum mark. If necessary, recoup the oil.</li> <li>3. Clean or replace filter for proper flow of oil.</li> <li>4. Pour hydraulic oil on intake joints and on observing abnormal sound, tighten the intake joint as required.</li> <li>5. Replace the broken shaft or rotor. Also align the prime mover shaft</li> <li>6. Pump should run at prescribed speed. Engine rpm should be checked.</li> <li>7. Replace the filter.</li> <li>8. Repair or change the valve</li> <li>9. Discharge air from the system</li> </ol>

S. No.	Faults	Probable Causes	Remedial Actions
2.	Pump makes noise	<p>10. Pump drive inoperative</p> <p>11. Clutch out of adjustment.</p> <p>12. Pump is damaged.</p> <p>1. Aeration.</p> <p>2. Intake line or suction filter partly clogged</p> <p>3. Pump running too fast.</p> <p>4. Coupling misaligned (Due to this bearing may get damaged, play at shaft may develop).</p> <p>5. Reservoir not vented properly.</p> <p>6. Suction filter too small in size.</p> <p>7. Air leaks at pump intake pipe joints and air drawn through inlet line.</p> <p>8. Oil viscosity too high. (In cold climate oil viscosity becomes high so no free flow will take place and cavitation will occur).</p> <p>9. Cavitation.</p>	<p>10. i) Replace the broken pump shaft. ii) Change defective coupling</p> <p>11. Adjust clutch</p> <p>12. Replace with new one.</p> <p>1) Fill the reservoir with the oil up-to required level to prevent aeration. ii) Check condition of pump shaft seal. Change, if required.</p> <p>2. Clean or replace the filter or line.</p> <p>3. Reduce speed up to prescribed limit.</p> <p>4. Realign the pump shaft and prime mover shaft</p> <p>5. Air breather screening element should be cleaned</p> <p>6. Replace by proper size of filter.</p> <p>7. Take action as explained in s.no.1, item no. 4.</p> <p>8. Start the engine for few minutes to warm-up the hydraulic oil used in machine for proper flow. Use only proper grade of oil.</p> <p>9. i) Check condition of suction filter and return line filters. Clean or change as necessary. ii) Check clogging of inlet line. Clean or change as necessary. iii) Check loose fittings on suction lines. Tighten, if required. iv) Clean hydraulic tank breather.</p>

S. No.	Faults	Probable Causes	Remedial Actions
3	Pump overheats	10. Shaft seal leaks.	10. Replace the seal.
		11. Foams in oil.	11. Vent the system.
		12. Casing leaks.	12. First tighten bolts, then check for cracks and sealing.
		13. Vane spring broken.	13. Change spring.
		14. Any part of pump defective.	14. Replace defective parts.
		15. Foreign bodies in suction line.	15. Remove foreign bodies. Flush the system if required.
		16. System dirty.	16. Flush the system
		17. Sharp bends in suction line.	17. Eliminate or reduce the bends in suction line.
		18. Oil temperature too high.	18. Check the hydraulic circuit. Oil cooler may be ineffective. Rectify the failure
		19. Boost pump failed.	19. Check boost pump and repair as required.
		20. Vibration in system	20. Check unusual occurrence in the system
		21. Pump worn out or damaged.	21. Pump should be overhauled or replaced.
		1. Wrong oil grade.	1. Fill oil as recommended.
		2. Oil speed in system too high.	2. Install pipes of proper size.
		3. Oil level too low.	3. Fill the oil up to safe level
		4. Pump rotor groove worn out	4. Change the worn out parts
		5. Radial or axial loading too high.	5. Loading should be restricted to prescribed limit. Check alignment limit.
		6. Initial speed rises	6. Check max. pressure. If needed replace with larger capacity and install pipe of nominal bore.

S. No.	Faults	Probable Causes	Remedial Actions
		7. Inadequate cooling 8. Cooling system is dirty. 9. Differential pressure too low 10. Pressure too high 11. Wrong type of pressure valve 12. Wrong seal size 13. Filter dirty or too small. 14. Pump running speed high 15. Cavitation 16. Foams in oil 17. Venting dirty 18. System contaminated 19. Sharp bends in suction line 20. Boost pump failed	7. Increase cooling capacity 8. Clean the cooling system. 9. Increase pressure setting of relief valve. 10. Reduce pressure setting 11. Replace by appropriate type of valve 12. Replace by suitable size of seal. 13. Clean filter or replace by larger size. 14. Reduce speed 15. Bleed the system 16. Vent the system 17. Clean the vents 18. Flush the system 19. Eliminate bends or at least reduce them 20. Check boost pump and repair as required
4	Pump develops no pressure	1. Wrong pressure setting 2. Pressure valve spool stuck 3. Leakage in system 4. Pump shaft broken 5. System contaminated 6. Improper gasket and seal	1. Modify the pressure setting 2. Repair/ Replace the valve. 3. Replace defective parts 4. Replace shaft 5. Flush the system completely. 6. Replace seals and gaskets
5.	Speed loss on pump.	1. Inlet pressure too low. 4. Outlet pressure too high. 3. Oil temperature too high.	3. Increase pressure. 2. Check system pressure. 3. Check the circuit.

S. No.	Faults	Probable Causes	Remedial Actions
6.	Pump does not work.	5. Pressure too low. 2. 'O' Ring on port plate defective. 3. Too much play in the shaft.	6. Increase pressure setting. 2. Replace 'O' Ring. 3. Replace bearing.
7.	Hydraulic oil overheated	1. System pressure is too high. 7. Dirty oil  3. Oil level is low. 4. Hydraulic oil of incorrect viscosity. 5. Faulty cooling system. 6. Internal leakage of hydraulic oil due to worn pump, valve, motor and cylinder.	1. Adjust the pressure to the required limit. 8. Clean or change filters and strainers. 3. Fill up the oil to the upper mark. 4. Check oil for proper viscosity. If, change of oil is required, flush the entire system and change filter before adding fresh oil. 5. Check oil cooler for trash on out side cooling surfaces. Clean with air pressure or steam pressure. 6. Overhaul or replace faulty components.
8.	Bearing failure.	1. Chips or other contaminants in bearing. 2. Coupling misaligned. 3. Inadequate lubrication. 4. Pump running too fast. 5. Excessive or shock loads. (Excessive loads due to operating pressure may damage the bearing).	1. Replace bearings and check intrusion of contaminants. 2. Align prime mover shaft and pump. 3. Lubricate system properly. 9. Adjust speed of prime mover. 5. Reduce operating pressure.

#### IV. HYDRAULIC RELIEF VALVE

S. No.	Faults	Probable Causes	Remedial Actions
1.	Erratic pressure.	1. Foreign material in the oil. 2. Worn poppet valve or seat. (oil from pilot stage will go to tank due to worn poppet valve or seat and pressure will drop). 3. Piston sticking in main body.	1. Drain the oil, clean the tank and refill with clean oil. 2. Replace poppet valve or seat as required. 3. Clean piston after dismantling. Check free movement after re-assembling .
2.	Low pressure or no pressure.	1. Valve improperly adjusted. 2. Vent connection is open. 3. Balance hole in main piston choked. 4. Poppet in cover not seating. 5. Broken or weak spring. 6. Dirt, chip etc keeps valve partially open.	1. Adjust valve by adjusting knob to proper pressure setting. 2. Plug the vent connection. 3. Remove piston and clean the orifice. Clean the tank and replace hydraulic oil. 4. Check the poppet condition. If required, replace it. 5. Replace the spring and again set the pressure with adjusting knob. 6. Clean the complete valve.
3.	Excessive noise or chatter.	1. High oil velocity through valve. 2. Distorted control spring. 3. Worn poppet. 4. Vent line too long.	1. Check valve flow rating. Replace with larger valve, if necessary. 2. Replace spring. 3. Replace the poppet. 4. Replace restrictions e.g. needle valve or orifice. Plug in vent line next to the relief valve.

S. No.	Faults	Probable Causes	Remedial Actions
4.	Valve do not function	5. Valve pressure setting too close to that of another valve in circuit. 1. Spool sticks. 2. Water condensation in system. 3. Oil temperature too high. 4. Oil speed too high. 5. Internal leakage. 6. Tank line under high pressure.	5. Set relief valve pressure at-least 150 PSI higher than other valves in circuit. 1. Clean stuck spool. 2. Check condensed water. 3. Check the function of oil cooler and clean the radiator fins. 4. Check speed of the pump. 5. Prevent leakage. 6. Check pressure in tank line.
5.	Valve heating over-	7. Control line dirty. 1. System pressure too high. 2. Dirt in the system. 3. Spool sticks. 4. Spool defective	7. Clean lines properly. 1. Adjust spring pressure. 2. Clean the system. 3. Check and clean spool. 4. Check and replace spool, if defective.

## V. HYDRAULIC UNLOADER VALVE

S. No.	Faults	Probable Causes	Remedial Actions
1.	Low or no pressure.	1. Orifice of main piston choked. 2. Vent connection open to tank. 3. Safety valve at zero setting 4. Broken or weak spring	1. Clean the orifice. 2. Plug the vent connection. 3. Set the safety valve at proper pressure. 4. Replace the spring.
2.	Fails to completely unload pump.	1. Valve pressure setting too high. 2. Valve spool binding in body. 3. Incorrect assembly. 4. Nil or low nitrogen pressure in the accumulator. 5. Punctured bladder.	1. Set valve at proper pressure. 2. Clean the spool or replace if required 3. Assemble as per proper drawing. 4. Check pressure and recharge the accumulator . 5. Change the bladder.

## VI. HYDRAULIC MOTOR

S. No.	Faults	Probable Causes	Remedial Action
1.	Motor makes loud Noise.	<ol style="list-style-type: none"> <li>1. Vane spring broken.</li> <li>2. Shaft seal leaks.</li> <li>3. Casing leaks.</li> <li>4. Oil temperature too high.</li> <li>5. Motor parts defective.</li> </ol>	<ol style="list-style-type: none"> <li>1. Change the spring.</li> <li>2. Replace the seal.</li> <li>3. First tighten bolts, then check for cracks and sealing.</li> <li>4. Check cooling circuits.</li> <li>5. Replace defective parts. Tighten bolts uniformly.</li> </ol>
2.	Motor overheats	<ol style="list-style-type: none"> <li>1. Motor is of under capacity</li> <li>2. Rotor worn out.</li> <li>3. Inadequate cooling.</li> <li>4. Pressure too high.</li> <li>5. Wrong seal size.</li> </ol>	<ol style="list-style-type: none"> <li>1. Install motor of proper capacity</li> <li>2. Change the rotor.</li> <li>3. Check cooling pump</li> <li>4. Reduce pressure setting on relief valve.</li> <li>5. Replace by suitable seals.</li> </ol>
3.	Speed loss on motor.	<ol style="list-style-type: none"> <li>1. Inlet pressure too low.</li> <li>2. Motor parts defective.</li> <li>3. Oil temperature too high</li> <li>4. Out let pressure too high</li> <li>5. Port plate does not make contacts.</li> </ol>	<ol style="list-style-type: none"> <li>1. Increase pressure by resetting relief valve.</li> <li>2. Change defective parts.</li> <li>3. Check cooling circuit. Hydraulic oil cooler may be defective.</li> <li>4. Check the system pressure.</li> <li>5. Dismantle the motor and repair as per requirement.</li> </ol>

## GENERAL SAFETY NOTES

1. The machine has to be operated as per existing Indian Railways rules and regulations.
2. The safety of yourself and other people is a most important consideration in the operation and maintenance of the machine.
3. Remember the machine is a working unit, carrying delicate instruments. Therefore the machine should not be driven at excessive speed over bad track or turnouts.
4. Always keep your eyes open for other men working close to the machine.
5. Do not forget to look out for signals, switches and track obstructions.
6. Remember to make sure that all protection equipment and safety devices are in place on the machine and in working order especially when it is being driven from one site to another.
7. Always keep the machine clean. Excessive oil or grease on the machine can cause you to slip or fall and is also a potential fire hazard.
8. Always lock the machine before you leave. Make sure that the machine is protected in accordance with railways regulations.
9. Whenever you have the opportunity while waiting to get out on a job, do some of the smaller maintenance jobs such as tightening loose nuts and bolts and cleaning the machine.
10. Do not permit unauthorized persons to operate the machine.
11. It is prohibited to use exposed light or fire on or near the machine.
12. Do not tow the machine if the final drive is engaged.

## **ACKNOWLEDGEMENT**

Following officers and staff have made their valuable contributions in finalization of Trouble Shooting Manual of Plasser make Work Site Tamper (08-32 New model).

### **RAILWAYS**

1. Shri. Muslim Ahmad Sr. Instructor/IRTMTTC/ALD
2. " S.K.Dhiman Sr. Instructor/IRTMTTC/ALD
3. " A.K. Gautam SE/TMC/NER

### **RDSO**

1. S/Shri H.C. Pandey Dy. Director/ Track Machines
2. " " Mohd. Naeem Siddiqui SE/Engg./TM.
3. " " O.P. Malhotra SE/Design/TM
4. " " A.N. Srivastava SE/Research/TM.
5. " " Prem Kumar SE/Research/TM