EINGANGE (INPUTS) - („X" gegen Masse) („X" to ground)

Symbol	Bezeichnung DESCRIPTION	Baugruppe .a-	Adr LP Ein	Symbol	Bezeichnung DESCRIPTION	Baugruppe .a-	Adr LP Ein	Symbol	Bezeichnung DESCRIPTION	Baugruppe .a-	Adr LP Ein
	tamp. units „down"		1X 1 | 0		COMPACTOR ON		2X 4 | 0			X | 0
	drive (work)		1X 1 | 1		COMPACTOR UP		2X 4 | 1			X | 1
	satellite forw.		2X 1 | 2		L.H. COMP ONLY		2X 4 | 2			X | 2
Rel.	left tamp.u. upper pos.	10u6 12d	X 1 | 3		R.H. COMP ONLY		2X 4 | 3			X | 3
Rel.	right tamp.u. upper pos.	10u7 12d	X 1 | 4		LIMIT S. COMPR. UPPER LIMIT LEFT.		X 4 | 4			X | 4
Rel.	left tamp.u. below middle pos.	10u5 12c	X 1 | 5		LIMIT S. COMPR. UPPER LIMIT RIGHT		X 4 | 5			X | 5
Rel.	right tamp.u. below middle pos.	10u7 12c	X 1 | 6		COMPR. LH. NOT LOWER		X 4 | 6			X | 6
Rel.	left tamp.u. lower pos.	10u6 12c	X 1 | 7		COMPR. R.H. NOT LOWER		X 4 | 7			X | 7
Rel.	right tamp.u. lower pos.	10u7 12c	X 1 | 8		front tens. bogie in upper pos. (V50)		1X 4 | 8			X | 8
	tamping syst. „on"		2X 1 | 9		rear lev. pick-up in upper pos. (V31)		1X 4 | 9			X | 9
	penetration assist „off"		2X 1 | A		COMPR. LH. LOCKED FRONT		X 4 | A			X | A
Rel.	satellite in front of middle pos.	10u5 12d	X 1 | B		COMP. R.H. LOCKED FRONT		X 4 | B			X | B
Rel.	satellite front pos.	10u5 12c	X 1 | C		left clamps u. lift or stop		2X 4 | C			X | C
	only left tamp.u. (impuls)		51X 1 | D		right clamps u. lift or stop		2X 4 | D			X | D
	only right tamp.u. (impuls)		51X 1 | E		bogie tension to left		2X 4 | E			X | E
	= delayed output Q1F		X 1 | F		bogie tension. to right		2X 4 | F			X | F
	lining & lev. start by units-down		2X 2 | 0		front jointflaps open or close		51X 5 | 0		COMPACTOR L.H. LOCKED REAR	1 X	9 | 0
	2. sign. satell. front pos.		1X 2 | 1		rear jointflaps open or close		51X 5 | 1		COMPACTOR R.H. LOCKED REAR	1 X	9 | 1
	satellite rear pos.		1X 2 | 2		satell. 1/f movem. auto mode „on"		2X 5 | 2		SQUEEZING FROUT ONLY	51 X	9 | 2
	reverse drive		51X 2 | 3		satell. man. contr. to left		2X 5 | 3		SQUEEZING REAR ONLY	51 X	9 | 3
	track sensor left clamp u.		1X 2 | 4		satell. man. contr. to right		2X 5 | 4			X	9 | 4
	track sensor right clamp u.		1X 2 | 5		satell. movem. sign. to right		1X 5 | 5		connected to ground only 09-16 type	X	9 | 5
	squeeze man. contr.		51X 2 | 6		satell. movem. sign. to left		1X 5 | 6			X	9 | 6
	auto cycle 1X		2X 2 | 7		plough down (extra)		33X 5 | 7			X	9 | 7
	auto cycle 12X		2X 2 | 8				X 5 | 8		SUBROUTINES	Q = X	9 | 8
	clamp units to upper pos.		2X 2 | 9		right sensor for auto pos.		1X 5 | 9			X	9 | 9
	close clamps if satell. stops		2X 2 | A		tamping units locked (V35)		1X 5 | A			X	9 | A
	clamps allw. closed (forw.-b.p.)		2X 2 | B				X 5 | P			X	9 | B
QL2E	left clamp u. down		2X 2 | C				X 5 | C			X	9 | C
QL2C	right clamp u. down		2X 2 | D				X 5 | D			X	9 | D
	auto levelling „on"		2X 2 | E				X 5 | E			X	9 | E
	track sensors for clamps „off"		2X 2 | F				X 5 | F			X	9 | F
	lining & lev. start t.u. middle pos.		2X 3 | 0		sensor distance expired (auto-p.)		X 7 | 0				X | A 0
	levelling lift & hold mode		2X 3 | 1		satell. distance expired		X 7 | 1				X | A 1
	left lift limitation	Q2E	X 3 | 2		auto position „stop"		52X 7 | 2				X | A 2
	right lift limitation	Q2C	X 3 | 3		sensor mode 1 v 2		52X 7 | 3				X | A 3
	satellite backward		2X 3 | 4		sensor mode 1 a 2		52X 7 | 4				X | A 4
	left sensor for auto pos.		1X 3 | 5		distance mode MEM (n-1)		52X 7 | 5				X | A 5
	auto position „on"		2X 3 | 6		distance mode MEM (const.)		52X 7 | 6				X | A 6
	drive step by step		2X 3 | 7		distance mode „const."		52X 7 | 7				X | A 7
	drive continuous		2X 3 | 8	Q78	⟶		X 7 | 8				X | A 8
	3 point lining „on"		2X 3 | 9	Q79	⟶		X 7 | 9				X | A 9
	close clamps by tamp u. down		2X 3 | A	Q7A	⟶		X 7 | A				X | A A
	lining unit man. contr. to left		2X 3 | B	Q7B	⟶		X 7 | B				X | A B
	lining unit man. contr. to right		2X 3 | C	Q7C	⟶		X 7 | C				X | A C
	auto lining „on"		2X 3 | D	Q7D	⟶		X 7 | D				X | A D
	lining without tamping		2X 3 | E	Q7E	⟶		X 7 | E				X | A E
	Satellite H.-DRIVE engaged		1X 3 | F				X 7 | F				X | A F

AUSGÄNGE (OUTPUTS)

← SIGNAL	SIGNAL →
Q10 left-tamp.u.down-angl. contr.	QL20 move satellite to left
10u6 12d. =6FA6EA5A (10)	=19A53 v19A52A0BA56 1s75 (18)
Q11 right-tamp.u.down, angl.contr.	QL21 move satellite to right
10u7 12d =6FA6DA5B (12)	=19A54 v19A52A0BA55 1s76 (18)
Q12 cycle clock	QL22 squeeze left, inside
Latch Ein = 08A01 Halten = 38A07v(38A0F) (12)	=9C 1s62 (14)
Q13 left clamps u. lift or stop	QL23 squeeze right, inside
out 2x4c ident Q02 (3)	=9D 1s63 (14)
Q14 right clamps u. lift or stop	QL24 brake (5bar) satell. drive
out 2x4b ident. Q03 (3)	=QFA18A1CA12A65A68A86' 1s443 v0BA34 v3EA10 v0D (17)
Q15	QL25 by-pass, satell. drive
	=37A11 (NO CURRENT = BYPASS) v09A38 v0BV(3EA10)V3F 1s451 v3EA10 (13)
Q16 track lowering left (servo)	QL26 brake (2bar) satell. drive
6u2 18d =2C v2EA08A02 v2EA05A3E (12)	=0FA1CA1F 1s452 (16)
Q17 track lowering right (servo)	QL27 front jointflaps open
6u3 18d =2D v2EA07A03 v2EA05A3E (13)	=66 1s457 (16)
Q18	QL28 rear jointflaps open
	=67 only 09-32 1s545 (17)
Q19 mach. stationary mode	QL29 clamps, closed (A)
=04 (7)	=(08v05v04A(28v62)A2C+2D+2EA4CA4D A09 1s529 (13)
Q1A	QL2A clamps, closed (B)
	ident. QL29 1s28 (19)
Q1B	QL2B left clamps unit down
(12)	ident. Q16 1s58 (12)
Q1C track lifting left (servo)	QL2C right clamps unit down
6u2 4b =(29v4C)A0B (11)	ident Q17 1s59 (13)
Q1D track lifting right (servo)	QL2D tamp. action counter
6u3 4b =(29v4D)A0B (11)	=08A01 1sg9 (20)
Q1E proc. run indic.	QL2E left clamps unit up
on 2b66 int. (13)	=(29v4C)A0B v09 1s3 (15)
Q1F time stage (ZG 5/6 on B7)	QL2F right clamps unit up
out 2x4c on =1C v22 X1F (13)	=(29v4D)A0B v07 1s4 (15)

← SIGNAL	SIGNAL →
Q30 assist cyl. satell. forw.	Q40 contr. sign. to a recorder
=085 1s441 (24)	ein = 08A01 halten = 0F (12)
Q31 plough down	Q41 satellite slowly forw.
=57A23 1s247 (24)	=61A89 10u8 12e6 (24)
Q32 clamps, open (A)	Q42 rev. drive latch
=28A62 v2Cv20v29v4Cv4D 1s453 (23)	LATCH on = 09 hold = 08 18u1 (c4) (23)
Q33 clamps, open (B)	Q43
ident. QL32 1s454 (23)	
Q34 lining unit „stop" to left	Q44 start: sensor dist. (auto pos)
=02 1s455 (3)	=78A01 6u4 10b (24)
Q35 lining unit „stop" to right	Q45 start: satell. dist.
=03 1s456 (3)	=(27v28)A(01v08) 6u4 16d (25)
Q36 satell. slowly backward	Q46 MEM impuls (auto pos.)
=34A08A(22v1F) v09A37A60 1s389 (on prop circ. too) (22)	=08A15A(27v28)A76 6u4 16b (25)
Q37 drive pump, enable	Q47 dist. mode „const."
=04 1s387 (on drive circ too) (7)	=77 6u4 30d (25)
Q38 bogie tension to left, Meas	Q48 LED sensor 1'
=4E 1s270 (26)	=35v78 52h1 (25)
Q39 bogie tension to right, Meas	Q49 LED sensor 2
=4F 1s271 (26)	=59v78 52h2 (25)
Q3A COMPACTOR UP L.H.	Q4A auto sign. tamp. u. down
=13A41 v QL3CA44 1s35 (21)	=Q64 X72 (15)
Q3B COMPACTOR UP R.H.	Q4B COMPACTOR NOT LOCKED
=14A41 v QL33A45 1s32 (21)	=4AV90 v48v97 (25)
Q3C COMPACTOR DOWN L.H.	Q4C mach. in lifting mode
=(10A3E)v08A40A43 1s34 (20)	= 06 v 07 (4)
Q3D COMPACTOR DOWN, R.H.	Q4D
=(10A3E)v08A40A42 1s36 (21)	
Q3E COMPACTOR HY-DRIVE ON, LH	Q4E
=40A48A43 1s430 (22)	
Q3F COMPACTOR HY-DRIVE ON, RH	Q4F
=40A47A42 1s431 (22)	

← SIGNAL	SIGNAL →
Q50	Q70
Q51	Q71
Q52	Q72
Q53	Q73
Q54	Q74
Q55	Q75
Q56	Q76
Q57	Q77
Q58	Q78 auto pos. sens. 1. impuls
	on = (35v59)A73 v 74A35A59 A36A38A0B hold = (0CvQ8)A36A38 (23) X78 X88
Q59	Q79 pos. sensor, gap: 1-2
	Latch on = 78A35A59 hold = 78 (24) X79 X89
Q5A SQUEEZING FRONT, BLOCKED	Q7A LATCH pos. sensor 2. impuls
=9E 1s323 (27)	on = (35v59)A73 A78A79 v 74A35A59 v95 hold = 78 v 95 (24) X7A X8A
Q5B SQUEEZING REAR, BLOCKED	Q7B all sens. imp. o.k.
= 9F 1s324 (27)	=78A79A7A X7B X8B
Q5C squeeze, left outside	Q7C dist. mode
= 26A6EA(01v(27A28) v 01A08A6EA(27v28) v 7DA6E (only 09-32) (14) 1s75	=75v76v77 X7C X8C
Q5D squeeze, right outside	Q7D penetration ass. close
= 26A6DA(01v(27A28) v 01A08A6DA(27v28) v 7DA6D (only 09-32) (14) 1s7	=15A16A0BA01A7EA(27v28)A1A X7D X8D
Q5E 3 point lining fork down	Q7E penetration ass. open
= 39 1s181 (14)	Latch on = Q81 hold = Q82 X7E X8E
Q5F SAT-SUPPORT BLOCKED	Q7F X8F
= QL29 1s362 (19)	

← SIGNAL	SIGNAL →
Q80 delay for Q0F	
set = 38A6F, 78 v 38A6FA28A04 X80	(6)
Q81 delay for Q1D	
set = 7D X81	(20)
Q82 delay for Q7E	
set = 7E X82	(23)
Q83 1 sec delay, Sat. Ass.	
=11A13A1AA0BA23 (1.009) X83	(7)
Q84 delay, tamp. u. up	
set = (66v67)A0B X84	(7)
Q85 delay for QL30	
set = 0FA18A3E X85	(20)
Q86 delay for QL24	
= 0FA39 Q5 sec X86	(17)
Q87 Q5 sec X87	
Q88 EXT. RAM MEMORY X88	
Q89 RAM for Q00 X89	(4)
Q8A RAM for Q05 X8A	(5)
Q8B X8B	
Q8C X8C	
Q8D X8D	
Q8E X8E	
Q8F X8F	

← SIGNAL	SIGNAL →
QCC flip-flop for auto cycle	Q08 subr. for driving
clock = 28A0B Reverse (23v23 v12) A00 X00 (2)	=37A11A6F v38A63A(23v6F) X08 (6)
Q01 subr. tamp.u. lower pos.	Q09 subr. rev. driving
=17A18 v17A6D v18A6E X01 (2)	=(37v38)A11A23A13A14A0B3A36 X09 (6)
Q02 latch, left clamp u. lift & stop	Q0A auto start, lining
on = 4C hold = 28A2C X02 (3)	=05A30A[(24A25)v2F]A(4Ev4F) X0A (7)
Q03 latch, right clamp u. lift & stop	Q0B subr. tamp u. down
on = 4D hold = 28A2D X03 (3)	=19A10A23A04A3EA27 v0EA3EA19A(10v54A72) X0B (8)
Q04 subr. mach. driving	Q0C latch, start conc. auto cycle
=08 v09 X04 (7)	on = 35A10 v0FA(13v21)A25A10 hold = 31v(28A63) X0C (9)
Q05 lift & lin. start enable	Q0D end of tamping (auto cycle)
=20A03 v30A63A15 v31A(05v19)A0F v3CA08A16 v3EA10 (5)	[LATCH, on = 31A(05v19)A0F hold = 04(28A0CA0F)] v2 X0D (7)
Q06 auto start, levell. left	Q0E latch for auto cycle
=2EA05A6EA32A28A49A(24v2F)A02 X06 (4)	on = 13A14A0C hold = (27v28)A(03v54)A0DA22 X0E (10)
Q07 auto start, levell. right	Q0F satell. forw. (auto cycle)
=2EA6EA6DA33A28A49A(25v2F)A03 A9E X07 (4)	=Q80A11A3E v3EA10A11A38 X0F (21)

← SIGNAL	SIGNAL →
Q60	Q68 latch for Q08 and Q41
X60	ein = 11A1CA38 halten = 38A11 X68 (30)
Q61 prop. sign. satell. forward	Q69 tamp. time expired, QOD
=(12v0F)A3EA6FA09 X61 (9)	time elaps. = (ZG 1/2) INPUT 7 time set = QOD 89 (ZGV2) time set = PROZ. RAM F X69 (7)
Q62 subr. for clamps logic	Q6A mem. for Q66 (int.)
=37A2AA0E v38A2AA(1C v0BA05) v3AA(03v05) X62 (11) X6A (16)	
Q63 latch, subr. for Q6F	Q6B mem. for Q67
X63 (24) X6B (17)	
Q64 latch, auto pos. sign. down	Q6C horn sign. rev. drive, START
on = (19A7EN(7AA2EA3C A38 A 0BA11 hold = (2ND): 3EA11A33 A (0CV0E) X64 (15) X6C	=(37v38)A11A23A13A14A0B3A36 (6)
Q65 latch for QL24	Q6D latch, only l. tamp u. down
on = 1B hold = (6B A 3E) v (10A3E) X65 (16) X6D (23)	on = 1D ON hold = 6F
Q66 flip-flop for X50	Q6E latch, only r. tamp u. down
clock = X50 X66 (16) X6E (23)	on = 1E hold = 6F
Q67 flip-flop for X51	Q6F delay, tamp. u. up (Q10, Q11)
clock = X51 only 09-32 X67 (17) X6F (26)	= 05 v 26 (27v28)A(15v16) LATCH, ON = (6Fv67)A0D HOLD = (6Fv67)A05

UNTERPROGRAMME (SUBROUTINES) X und O verbunden (X and O wired)	← SIGNAL	SIGNAL →
	X98	
	X99	
	X9A	
	X9B	LATCH, SQUEEZING ON = 19A(92v93) LATCH = 19A9CA9D (31)
	X9C	SQUEEZING L.H. =26A(01v(27A28) v01A08A(27v28) v7D)A6E (14)
	X9D	SQUEEZING R.H. =26A(01v(27A28) v01A08A(27v28) v7D)A6D (14)
	X9E	SQUEEZING BLOCKED, FRONT =9BA92 (31)
	X9F	SQUEEZING BLOCKED, REAR =9BA93 (31)

LOGIC PLAN OF CSM

for: [symbol] Q53, Q54, Q55, Q56, Q57, Q58, Q59, Q5A, Q5B, Q5C, Q5D, Q5E, Q5F, 12A, 12B, 12C, 12D, 12E, 12F, 2x...

for: [symbol] Q53, Q54, Q55, Q56, Q57, Q58, Q59, Q5A, Q5B, Q5C, Q5D, Q5E, Q5F, 2x...

A = and
v = or
30 = 20 not
Latch = hold mode
(23) = progr. sheet nr.

Q5 sec

output Q0L

Leistungsausgang (Power output)

power output

siehe I/O Plan (see I/O circuit)

layout

Q6E

Q6D

Q6F

Q6C

Q6B

Q6A

Q68

Q69

Q60

Q61

Q62

Q63

Q64

Q65

Q66

Q67

Q08

Q09

Q0A

Q0B

Q0C

Q0D

Q0E

Q0F

Q01

Q02

Q03

Q04

Q05

Q06

Q07

Q00

Q10

Q11

Q12

Q13

Q14

Q15

Q16

Q17

Q18

Q19

Q1A

Q1B

Q1C

Q1D

Q1E

Q1F

QL2E

QL2C

QL2D

QL2F

QL2A

QL2B

QL26

QL27

QL28

QL29

QL20

QL21

QL22

QL23

QL24

QL25

QL3E

QL3F

QL30

QL31

QL32

QL33

QL34

QL35

QL36

QL37

QL38

QL39

QL3A

QL3B

QL3C

QL3D

Q70

Q71

Q72

Q73

Q74

Q75

Q76

Q77

Q78

Q79

Q7A

Q7B

Q7C

Q7D

Q7E

Q7F

Q80

Q81

Q82

Q83

Q84

Q85

Q86

Q87

Q88

Q89

Q8A

Q8B

Q8C

Q8D

Q8E

Q8F

Q50

Q51

Q52

Q53

Q54

Q55

Q56

Q57

Q58

Q59

Q5A

Q5B

Q5C

Q5D

Q5E

Q5F

Q40

Q41

Q42

Q43

Q44

Q45

Q46

Q47

Q48

Q49

Q4A

Q4B

Q4C

Q4D

Q4E

Q4F

Q30

Q31

Q32

Q33

Q34

Q35

Q36

Q37

Q38

Q39

Q3A

Q3B

Q3C

Q3D

Q3E

Q3F

Q98

Q99

Q9A

Q9B

Q9C

Q9D

Q9E

Q9F

X98

X99

X9A

X9B

X9C

X9D

X9E

X9F

X68

X69

X6A

X6B

X6C

X6D

X6E

X6F

X08

X09

X0A

X0B

X0C

X0D

X0E

X0F

X01

X02

X03

X04

X05

X06

X07

X00

X10

X11

X12

X13

X14

X15

X16

X17

X18

X19

X1A

X1B

X1C

X1D

X1E

X1F

X30

X31

X32

X33

X34

X35

X36

X37

X38

X39

X3A

X3B

X3C

X3D

X3E

X3F

X78

X79

X7A

X7B

X7C

X7D

X7E

X7F

X88

X89

X8A

X8B

X8C

X8D

X8E

X8F

X50

X51

X52

X53

X54

X55

X56

X57

X58

X59

X5A

X5B

X5C

X5D

X5E

X5F

X48

X49

X4A

X4B

X4C

X4D

X4E

X4F

X40

X41

X42

X43

X44

X45

X46

X47

X18

X19

X1A

X1B

X1C

X1D

X1E

X1F

X28

X29

X2A

X2B

X2C

X2D

X2E

X2F

X20

X21

X22

X23

X24

X25

X26

X27

X10

X11

X12

X13

X14

X15

X16

X17

X58

X59

X5A

X5B

X5C

X5D

X5E

X5F

X48

X49

X4A

X4B

X4C

X4D

X4E

X4F

X40

X41

X42

X43

X44

X45

X46

X47

X38

X39

X3A

X3B

X3C

X3D

X3E

X3F

X30

X31

X32

X33

X34

X35

X36

X37

X28

X29

X2A

X2B

X2C

X2D

X2E

X2F

X20

X21

X22

X23

X24

X25

X26

X27

X10

X11

X12

X13

X14

X15

X16

X17

X08

X09

X0A

X0B

X0C

X0D

X0E

X0F

X00

X01

X02

X03

X04

X05

X06

X07

X98

X99

X9A

X9B

X9C

X9D

X9E

X9F

X68

X69

X6A

X6B

X6C

X6D

X6E

X6F

X60

X61

X62

X63

X64

X65

X66

X67

X78

X79

X7A

X7B

X7C

X7D

X7E

X7F

X88

X89

X8A

X8B

X8C

X8D

X8E

X8F

X50

X51

X52

X53

X54

X55

X56

X57